

CRIME STOPPER

SAFETY & SECURITY

This diagram was made to show you how to add the A-DS-101 shock sensor to a single wire input on an EVO-ALL or EVO-ONE.

You will need to turn option "G" on in the flashlink manager to activate the alarm features of the EVO products. Then you will need document guide #12971 to show you what additional wires are used for the alarm wiring.

Following the diagram below will show you how to connect the A-DS-101 to the EVO product.

