MyCar Telematics Supported Features

Legend: ● Supported
● Not tested Yet

Last Updated : September 26, 2017

Notes: (1): Connect the Telematics device using the HRN-MCAR-01 directly to the BLACK RS232 Port.
(2): Blade-AL (64) MUST be used for full connectivity with remote starter functions.
(3): Engine Will Start
(4): Must enable in remote starter menu option: Smart Phone Baud Rate to Option #1 (9600).
(5): Connect the Telematics device using the HRN-MCAR-01 + HRN-LLRS-01 with White 4 pin connector. Connect to White Data port on side of Remote starter unit.
(6): NOT RECOMMENDED ON MANUAL TRANSMISSION MODE.
(7): NOT compatible
(8): Connect the Telematics device using the HRN-MCAR-01 directly to the BLUE RS232 Port.
(9): Power and Ground required only.

	MyCar	ADS				CrimeStopper					Compustar		Directed				Fortin	
Remote Starter Brand/Model	**STANDALONE**	**HC**	**ADS-AL-CA**	**AKX**	**BM - BZ**	**RS-00**	**RSx-G5**	**SP-302**	**SP-402**	**SP-502**	**CM-6200**	**CM-7200**	**DBALL2**	**DB3**	**IX10 / 5X10**	**DS4 / DS4+**	**EVO-ALL**	**EVO-ONE**
Applicable Notes:	(9)	(8)	(7)	(8)	(8)	(4) (5)	(4) (5)	(7)	(4) (5) (6)	(4) (5) (6)	(1) (2)	(1) (2)						
BASIC FUNCTIONS																		
Communication Protocol Required	Standalone	ADS	-	ADS	ADS	ADS	ADS	ADS	ADS	ADS	ADS	ADS	DEI	DEI	DEI	DEI	Fortin	Fortin
Lock		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Unlock		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Start (Engine Off)		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Start (Engine On) Extended runtime		●																
Start Confirmation beep Phone Unlocked		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Start Confirmation beep Phone Locked		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Runtime Display On (after start command)		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Runtime display Refresh on returning to App		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Stop (Engine On)		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Stop (Engine Off)		●		●	(3)	●	●		●	●	(3)	(3)	●	●	●	●	●	●
Stop Confirmation beep Phone Unlocked		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Stop Confirmation beep Phone Locked		●		●	●	●	●		●	●	●		●	●	●	●	●	●
Runtime Display Off (after stop command)		●		●	●				●	●	●	●	●	●	●	●	●	●
Trunk Release / Motorized Liftgate Open		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
Motorized Liftgate Close		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
AUX 1 (LSD)		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
AUX 2 (RSD)		●		●	●	●	●		●	●	●	●	●	●	●	●	●	●
AUX 3		●																
AUX 4		●																
STATUS																		
Temperature °C																		
Battery Level	●	●		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Generic Alarm Notification (+ Yellow wire)	●	●		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
GPS Position (Instant Position)	●	●		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●